

HTM 6504iB Door Alarm

Operation.

Checking the Door Monitor status:

Place the iButton on the reader

If the light flashes Red, the unit is **ON** (armed)

If the light flashes Green, the unit is **OFF** (disarmed)



To turn the Door Monitor ON:

Close the door.

Place the iButton on the reader, it will flash green.

Within five seconds, press the **Reset** Button once.

The unit beeps then flashes the Red light to indicate it is now **ON**

If the door is opened the unit will activate and the red reassurance light will flash every five seconds until the unit is reset.

To reset the Door Monitor after an alarm:

Close the door

Place the iButton on the reader.

The unit will beep and the light will flash for five seconds.

If the unit is reset with the door open, it will re-arm as soon as the door is closed.

Note: If the unit is not reset, door alarms will auto reset after 10mins.

To turn the Door Monitor OFF:

Close the door

Place the iButton on the reader, it will flash red.

Then immediately press the Reset Button once.

The unit beeps then flashes the Green light to indicate it is now

OFF

To make an emergency call manually:

Press the red **Emergency** button. The light will flash every five seconds until the unit is reset.

Reset as above.

